

Long Haul Expedition Tuckunder and Velcro Tuckunder Spraycover Assembly instructions

SPRAYCOVERS

We manufacture two styles of spraycovers; the Velcro tuck-under and Expedition tuck-under. Both are installed in the same manner. Installation of the Velcro style will be easier with the skirts open.

1. Air sponsons should be inflated about half way. Locate the flat lace, which is sewn to the inside of the rubber piece on the front end of your spraycover. Tuck this lace under the front edge of the mast bracket.
2. Pull the spraycover to the rear of the cockpit and hook the grommets over the screws on the rear coaming piece. (Shown right)
3. The expedition spraycover has two metal hooks sewn onto the rear rubber piece. Hook these under the rear coaming piece.
4. Tuck one long edge of the spraycover between the coaming and the deck so that the rope in the edge of the spraycover fits snugly into the shallow groove on the inside of the coaming.
5. Repeat for the other side.
6. Fully inflate your sponsons.

